

Industrial Computer Source

Product Manual

Model EXM-12

Reference Manual

MANUAL NO. 41417-080-02A

Industrial Computer Source 10180 Scripps Ranch Blvd., San Diego, CA 92131 (619) 271-9340

Industrial Computer Source France (1)69.07.28.22 Industrial Computer Source Asia Pte. Ltd. 65-749-0800
Industrial Computer Source (UK) Ltd. 0243-533900 Industrial Computer Source (Deutschland) GmbH (2234)

This page intentionally left blank.

FORWARD

This instruction manual provides the necessary user information for the referenced product(s) manufactured or distributed by Industrial Computer Source for the user to install, operate and/or program the product properly. Please refer to the following pages for information regarding the warranty and repair policies.

Technical assistance is available at (619) 271-9340.

Manual Errors, Omissions and Bugs: A Bug Sheet is included as the last page of this manual. Please use it if you find a problem with the manual you believe should be corrected.

NOTICE

The information in this document is provided for reference only. Industrial Computer Source does not assume any liability arising out of the application or use of the information or products described herein. This document may contain or reference information and products protected by copyrights or patents and does not convey any license under the patent rights of Industrial Computer Source, nor the rights of others.

Printed in the U.S.A. Copyright© 1993 by Industrial Computer Source, a California corporation, 10180 Scripps Ranch Blvd., San Diego, CA 92131. All rights reserved.

This page intentionally left blank.

INDUSTRIAL COMPUTER SOURCE GUARANTEE, LIMITED WARRANTY AND RETURN POLICY

***LIMITED WARRANTY:** One year limited warranty on all products sold with the exception of the "Performance Series" I/O products, which are warranted to the original purchaser for as long as they own the product, subject to all other conditions below, including those regarding neglect, misuse and acts of God. Within one year of purchase, we will repair or replace, at our option, any defective product sold by us. At any time after one year, we will repair or replace, at our option, any defective "Performance Series" I/O product sold by us. This does not include products damaged in shipment, or damaged through customer neglect or misuse.

The Return Procedure below must be followed to assure repair or replacement. We will normally return your replacement or repaired item via UPS Blue. Overnight delivery or delivery via other carriers is available at additional charge.

The limited warranty is void if the product has been subjected to alteration, neglect, misuse, or abuse; if any repairs have been attempted by anyone other than Industrial Computer Source or its authorized agent; or if the failure is caused by accident, acts of God, or other causes beyond the control of Industrial Computer Source or the manufacturer. Neglect, misuse, and abuse shall include any installation, operation, or maintenance of the product other than in accordance with the owners' manual.

No agent, dealer, distributor, service company, or other party is authorized to change, modify, or extend the terms of this Limited Warranty in any manner whatsoever. Industrial Computer Source reserves the right to make changes or improvements in any product without incurring any obligation to similarly alter products previously purchased.

***GUARANTEE:** Thirty day money-back guarantee on all standard products sold. Special order products are covered by our Limited Warranty, however they may not be returned for refund or credit.

REFUNDS: In order to receive a full refund of product purchase price, the product must not have been damaged by the customer or by the common carrier chosen by the customer to return the goods, and the product must be returned complete (meaning all manuals, software, cables, etc.) within 30 days of receipt and in as-new and resalable condition. **RETURN PROCEDURE** below must be followed to assure prompt refund.

RESTOCKING CHARGES: Product returns after 30 days, and before 90 days, after purchase will be subject to a minimum 20% restocking charge and any charges for damaged or missing parts.

Products not returned within 90 days of purchase, or products which are not in as-new and resalable condition, are not eligible for credit return and will be returned to the customer.

RETURN PROCEDURE: For any Limited Warranty or Guarantee return, every product returned to Industrial Computer Source for service or credit must be accompanied by a Return Material Authorization (RMA) Number, obtained from Industrial Computer Source Customer Service, (619) 271-9340, prior to its return. Freight on all returned items must be prepaid by the customer and customer is responsible for any loss or damage caused by common carrier in transit. Returns for warranty must include a failure report for each unit, by serial number as well as a copy of the original invoice showing date of purchase.

To reduce risk of damage, returns of product must be in an Industrial Computer Source shipping container. If the original container has been lost or damaged, new shipping containers may be obtained from Industrial Computer Source Customer Service at a nominal cost.

SHIPMENTS NOT IN COMPLIANCE WITH THIS GUARANTEE AND LIMITED WARRANTY RETURN POLICY WILL NOT BE ACCEPTED BY INDUSTRIAL COMPUTER SOURCE.

LIMITATION OF LIABILITY: In no event shall Industrial Computer Source be liable for any defect in hardware or software or loss or inadequacy of data of any kind, or for any direct, indirect, incidental, or consequential damages in connection with or arising out of the performance or use of any product furnished hereunder. Industrial Computer Source liability shall in no event exceed the purchase price of the product purchased hereunder. The foregoing limitation of liability shall be equally applicable to any service provided by Industrial Computer Source or its authorized agent.

* Some sale items and custom systems are not subject to the guarantee and limited warranty above, however in these instances any deviations will be disclosed prior to sale and noted on the original invoice. We reserve the right to refuse returns or refunds on software or special order items.

This page intentionally left blank.

TABLE OF CONTENTS

CHAPTER 1	1
PRODUCT DESCRIPTION	1
CHAPTER 2	3
INSTALLATION	3
INSERTION IN AN EXM CARRIER	3
CONFIGURING THE BIOS SETUP	3
ENABLING THE EXM MODULE	4
CHAPTER 3	7
PROTOTYPING	7
PAL EQUATIONS	7
DEFAULT PAL CODES	8
CHAPTER 4	9
THE EXM EXPANSION INTERFACE	9
EXM EXPANSION INTERFACE SIGNAL DEFINITIONS AND PIN-OUT	9
USING THE EXM EXPANSION INTERFACE	12
PROGRAMMING INTERFACE	13

REVISION HISTORY

August 1993 New Release

This page intentionally left blank.

CHAPTER 1

PRODUCT DESCRIPTION

This manual contains the information you will need to install and use the EXM-12 prototyping module.

The EXM-12 is a prototyping module for use with products compatible with the EXM expansion interface. The EXM-12 printed circuit board is filled with an array of holes spaced 100 mils apart, along with hole spacing for inserting a 40-pin header at the front of the board.

It contains EXM expansion interface logic and two user-programmable PALs (part number T1BPAL2018-15) for decoding the EXM expansion interface transactions. These PALs are socketed 24-pin PALs. The EXM-12 is shipped with these PALs installed and programmed to a default configuration.

A floppy diskette is provided with the EXM-12 containing ABEL-compatible source files for the PALs as well as an OrCAD-compatible schematic file and its archive library.

This page intentionally left blank.

CHAPTER 2

INSTALLATION

Before installing the EXM-12, unpack and inspect it for shipping damage.

- Do not remove the module from its anti-static bag unless you are in a static-free environment. The EXM-12, like most other electronic devices, is susceptible to ESD damage. ESD damage is not always immediately obvious, in that it can cause a partial breakdown in semiconductor devices that might not immediately result in a failure.
- Ensure that the installation process as described herein is also performed in a static-free environment.

INSERTION IN AN EXM CARRIER

Insertion of the EXM-12 into an EXM carrier is straightforward. Remove a blank EXM panel from the carrier (by unscrewing the thumbscrews) and insert the EXM-12 into the card guides. Firmly press the EXM-12 front panel to ensure that the module is properly seated in the subplane, and secure it with thumbscrews.

- Make sure that the power to your system is off. The EXM is not designed to be inserted or removed from a live system.
- When inserting the EXM, avoid touching the circuit board, and make certain the environment is static-free.
- Insert it with adequate continuous force rather than tapping or hammering on it.

CONFIGURING THE BIOS SETUP

The EXM configuration data in the EPC to which the EXM-12 is connected needs to be modified to recognize and enable the card and select from the available options. From the command line, invoke the BIOS setup function by pressing the CTRL-ALT-ESC keys simultaneously.

ENABLING THE EXM MODULE

Once in the setup program, a menu display specifying which function keys are available for further configuration. Press the F2 function key to invoke the EXM menu. The screen display resembles Figure 1 below.

	ID	OB1	OB2
Slot 0	FF	00	00
1	DB	C1	00
2	F3	05	00
3	DE	00	39
4	ED	01	00
5	DC	F5	91

Figure 1. EXM Setup Screen


The setup screen displays the EXM configuration data (in hexadecimal) stored in nonvolatile memory which the EPC uses at power-up to recognize and configure each installed EXM. The displayed data shows SLOT, ID, OBI and OB2 for each installed EXM.

Note that all slots are listed on the screen even if the actual system configuration does not have all the possible EXM slots. All slots not occupied by an EXM module should show an ID of FF and OBI/OB2 of 00. 00 indicating that no EXM is present. A typical value for the EXM-12 is shown in bold letters in slot 2.

Slot, OBI and OB2 are defined as follows.

SLOT Indicates the slot in which the EXM is installed. See the diagram below to determine which EXM slot the EXM-12 occupies. Note that the dashed lines indicate EXM slots that may not be available on all systems.

Figure 2. EXM Slot Numbering



ID is a hard-wired ID value. Each EXM has a unique ID value.

OBI/OB2 are two bytes of option information.

To add or change an EXM configuration, use the cursor keys (arrows) to move between the fields on the screen. Move the cursor to the appropriate slot entry and type in the correct value.

The for the EXM-12 should be set to F3h.

OBI is a hexadecimal value derived by combining the following:

- Bit 7 through 4 are unused.
- DMA channel 1 configured using bit 3.
- The interrupt is configured using bits 2-1.
- The card is enabled or disabled using bit 0.

OB2 is not used.

Bit 3 DMA Channel 1	Bits 2-1 Interrupt	Bit 0 EXM enable
0 DMA Disable	00 none	0 Disable
1 DMA Enable	01 IRQ9	1 Enable
	10 IRQ5	
	11 IRQ15	

Table 1. OBI Setting

For instance, a typical OBI value is 05h (00000101), representing DMA is disabled, interrupt 5 is enabled, and the EXM-12 is enabled. When selecting options, take care that there are no conflicts with other EXM modules. For instance, many of the other EXM modules have programmable interrupts and DMA channels. If more than one device is configured for a given interrupt, unstable conditions could result.

This page intentionally left blank.

CHAPTER 3

PROTOTYPING

PAL EQUATIONS

The EXM-12 contains three PALS, two of which are socketed DIP parts which may be replaced by the user. The EXM-12 is shipped with two installed preprogrammed PALS containing a default configuration. The third PAL, which is not user changeable, implements the EXM-12 configuration option byte register.

One socketed PAL, U1, is intended for I/O port address decode. There are two I/O address ranges: 0-3FF and 8000-83FF, U1 is connected to the following signals shown on Table 2.

Inputs	Outputs	I/Os
SA[15..9..0]	SDENI-	IOSPARE[2..1]-
AEN	SDDIRI-	
IOR-	CS_IOX-	
IOW-	CS_IOZ-	
CDEN	IOSPAREO	
ACMID-		

Table 2. U1 Signals.

Another socketed PAL, U2 is intended for memory address decode. The memory address range is 010000 - FFFFFF in 64K byte blocks. U2 is connected to the following signals.

Inputs	Outputs	I/Os
LA[23..17], SA16	MEMCS16-	MEMSPARE[4..1]-
DACK-	SDDIR-	
MEMW-	SDEN-	
MEMR-	MEMSPAREO-	
SDDIRI		
SDENI-		
CDEN		

Table 3. U2 Signals.

Please refer to the files included on the distribution diskette for the PAL equations. For example, the file IODEC.ABL contains the following equations:

```
sddir1 = ior;
sden1 = (cden & !aen & (ioadr >=^h2C0) & (ioadr <=^h2C7) & (ior # iow))
        #!aen & ior & (ioadr ==^h100) & acmid
        #(!aen & (ioadr ==^h102) & acmid & (ior # iow));
cs_IOX = !aen & (ior & (ioadr ==^h100) # (ioadr ==^h102)) & acmid;
iospare0 = cden & !aen & (ioadr ==^h2C0) & (ioadr <=^h2C7);
iospare1 = 1;
iospare2 = 2;
```

When modifying the PAL in locations U1 and U2, it is important to preserve certain mini -terms in the equations for CX_IOX, SDDIR1, SDEN1, SDDIR and SDEN. These signals control logic on the EXM-12 to enable the EXM-12 ID and option byte registers. There are specific notes in the source code that describe these issues.

DEFAULT PAL CODES

Default PAL codes do not implement the BALE signal. This signal is not necessary for I/O mapped boards, but is necessary for memory-mapped boards.

CHAPTER 4

THE EXM EXPANSION INTERFACE

The EXM Expansion Interface is used to provide local expansion of embedded PCs within the context of a larger systems architecture. Electrically, the EXM expansion interface is nearly identical to the 16-bit PC/AT Industry Standard Architecture bus (ISA bus). The difference include the following:

1. **RESETDRV** is negative true in the EXM expansion interface and is positive true in the ISA bus.
2. **DMA channel 7**, which consists of signals **DRC7** and **DACK7**, is not present in the EXM expansion interface.
3. The signals **SA{17..19}** are not present in the EXM expansion interface.
4. The addition of a signal line (**EXMID**) for EXM module identification.
5. The signal **SBHE** is negative true in the EXM expansion interface and the ISA bus. Some versions of the ISA bus documentation from IBM incorrectly define this signal as a positive true signal.

The **EXMID** line allows the individual expansion modules to be uniquely addressed at power-up, and facilitates software configuration as an alternative to jumpers and switches. This software configuration feature is incorporated into the EXM expansion interface in such a way that unmodified PC add-in card software can be used by EXM expansion modules. The registers that use this feature are described later in this chapter.

EXM EXPANSION INTERFACE SIGNAL DEFINITIONS AND PIN-OUT

The EXM expansion interface signals use the same names and timing as the IBM PC/AT bus signals. The only exceptions to this are the **-RESETDRV** signal, which is inverted in the EXM expansion interface, and the **-EXMID** signal, which is unique to the EXM expansion interface.

The **-EXMID** signal is routed to each slot and asserted by the CPU board depending on the value of register 96. In addition, the **-EXMID** signal is routed to each EXM slot to access the ID register (address 100H) and the programmable options select registers (addresses 102H and 103H). The **-EXMID** and **-RESETDRV** registers are used to perform module identification and configuration under software.

Refer to the *IBM Technical Reference; Personal Computer AT* document number 6139362 pages I-31 through I-37 for the PC/AT bus signal descriptions.

Table 4 provides the pin-out for the EXM expansion connector. The A row is on the component side of the EXM module, where it is populated with PALs, gates, and capacitors. Pin A1 is located on the bottom of the card, when the card is inserted vertically into the expansion interface with the label oriented properly. The B side of the EXM-12 is populated only with smaller resistors and capacitors.

Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
A1	+12V	B1	GND	A30	-DACK5	B30	-IOR
A2	reserved	B2	reserved	A31	-DACK3	B31	-SMEMW
A3	+5V	B3	GND	A32	-DACK2	B32	-SMEMR
A4	+5V	B4	GND	A33	reserved	B33	GND

A5	SD15	B5	SD14	A34	-DACK1	B34	-MEMW
A6	SD13	B6	SD12	A35	-DACK0	B35	-MEMR
A7	SD11	B7	SD10	A36	-SBHE	B36	BALE
A8	-12V	B8	GND	A37	+5V	B37	CLK
A9	SD9	B9	SD8	A38	AEN	B38	GND
A10	SD7	B10	SD6	A39	LA23	B39	LA22
A11	SD5	B11	SD4	A40	LA21	B40	LA20
A12	+12V	B12	GND	A41	LA19	B41	LA18
A13	SD3	B13	SD2	A42	LA17	B42	SA16
A14	SD1	B14	SD0	A43	TC	B43	GND
A15	IRO15	B15	IRO14	A44	SA15	B44	SA14
A16	IRO12	B16	GND	A45	SA13	B45	SA12
A17	IRO11	B17	IRO9	A46	key	B46	key
A18	IRO7	B18	IRO6	A47	key	B47	key
A19	IRO5	B19	IRO4	A48	SA11	B48	SA10
A20	+5V	B20	IRO3	A49	SA9	B49	SA8
A21	-EXMID	B21	-RESETDRV	A50	OSC	B50	GND
A22	-IOCHCK	B22	GND	A51	SA7	B51	SA6
A23	DRO6	B23	IOCHRDY	A52	SA5	B52	SA4
A24	DRO5	B24	-OWS	A53	SA3	B53	SA2
A25	DRO3	B25	-IOCS16	A54	SA1	B54	SA0
A26	DRO2	B26	-MEMCS16	A55	+5	B55	GND
A27	DRO1	B27	-REFRESH	A56	+5	B56	GND
A28	DRO0	B28	GND	A57	reserved	B57	reserved
A29	-DACK6	B29	-IOW	A58	+12	B58	GND

Table 4. EXM Signal Pin-out.

A subset of the EXM expansion interface, along with several other useful signals, are routed to two header locations (JP3 and JP4) just in front of the card edge connector. Refer to Figure 3 on 13. These header locations can be used to wire the signals to other prototype logic that the user wishes to install. Users can either connect directly to the holes or add a header and wire wrap from these signals to the user logic. Table 4 defines the signal pin-out for these headers.

JP4				JP3	
Pin	Signal	Pin	Signal	Pin	Signal
1	SA1	29	SA0	1	SA2
2	SA4	30	SA3	2	SA5
3	SA7	31	SA6	3	OSC
4	SA9	32	SA8	4	SA10
5	SA12	33	SA11	5	SA13

6	SA15	34	SA14	6	TC
7	LA17	35	SA16	7	LA18
8	LA20	36	LA19	8	LA21
9	LA23	37	LA22	9	AEN
10	-SBHE	38	SCLK	10	BALE
11	-MEMR	39	-DACKO	11	-MEMSPARE3
12	-IOSPAREO	40	-MEMW	12	-SMEMR
13	-SMEMW	41	DRO	13	-DACKS
14	-IOSPAREI	42	-IOR	14	-IOW
15	-IOSPARE2	43	DROO	15	-REFRESH
16	MEMCS16	44	USRO	16	-MEMSPARE2
17	DROS	45	-IOCS16	17	-OWS
18	IOCHRDY	46	USR1	18	-IOCHCK
19	-RESETDRV	47	-EXMID	19	CDEN
20	IRO4	48	USR2	20	-MEMSPAREO
21	IRO11	49	INT	21	-MEMSPAREI
22	-MEMSPARE4	50	USR3	22	-DACK
23	DO	51	D1	23	D3
24	D5	52	D2	24	D4
25	D6	53	D7	25	SD9
26	-I2V	54	SD8	26	SD11
27	SD13	55	SD10	27	SD12
28	SD14	56	SD15	28	+I2

Table 5. Prototyping Interface Connector

In the preceding table, the following signals are buffered versions of the EXM Expansion Interface signals: TC, AEN, SCLK, BALE, -SBHE, -MEMR, -MEMW, -SMEMR, -RESETDRV. The signals DO-D7 are buffered by a bi-directional buffer. The signals USRO-USR3, MEMSPAREO-MEMSPARE4, IOSPAREO-IOSPARE2, -DACK, INT, DRO and CDEN connect to logic or spare PAL pins on the EXM-12.

The remaining signals are directly connected to the EXM expansion interface edge connector.

Note that pin 1 on the PALs and the capacitors on the JP1, JP2, JP3 and JP4 is always denoted by a squared outline around the round hole. Similarly, pin 1 on the socketed PALs is always denoted by a squared outline. Squared holes on the capacitors are +5V, while round holes are ground.




Figure 3. EXM-12 Layout.

USING THE EXM EXPANSION INTERFACE

1. For all I/O reads and writes, be sure to gate the decode with AEN deasserted. This ensures that DMA activity will not trigger an I/O access to I/O ports defined on the prototype card. Sample equations are provided on Chapter 3.
2. When generating MEMCSI6, only use addresses LA17-LA23. The timing of SA0-SA16 is too late to guarantee sufficient setup time to the EXM expansion interface controller chip on the CPU board.
3. Take care when configuring the ports on the EXM-12 that the I/O addresses and memory addresses for the port do not conflict with addresses used by the CPU or other EXMs in the system. Please refer to the respective hardware reference manuals to determine potential conflicts. If there are conflicts, it is possible that permanent damage could occur to the components of the EPC or other EXM products. For instance, the EXM-12 may conflict with the EXM-

IOA if one enables the EXM-IOA buffer memory in the D-page. This is because the default configuration for the EXM-12 also has the D-page enabled.

4. Gate all functions on the prototype card with the CDEN signal. In other words, disable all I/O regions, memory regions, interrupt generations, and DMA usage if CDEN is not asserted.
5. When decoding both I/O and memory addresses on the EXM-12, take care that the control strobes (e.g., IOR, MEMR) are gated with any data enables to the EXM expansion interface. Otherwise, it is possible that the memory accesses can cause I/O decodes and vice versa, causing conflicts with other modules.

PROGRAMMING INTERFACE

The EXM-12 defines the following registers in the I/O space.

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	I/O port
Device ID register	1	1	1	1	0	0	1	1	100
Config Option Byte 1 Reg	User-specified				Drq	Interrupt	CDEN		102

Figure 4. EXM-12 Registers in I/O Space

Registers 100 and 102 are standard EXM registers for device identification and configuration. The EXM-12 responds to accesses to these ports only if EXM expansion interface line -EXMID is asserted. An 8-bit read from I/O address 100h returns the value F3, the device ID of the EXM-12. A read/write configuration register appears at I/O address 102h. The bit encodings are defined in Chapter 2.

User Specified bits can be used for any purpose that the user wants. These bits are read/write bits and the outputs from the register can be used to control other logic on the prototype card. These bits are available as signals USRO-USR3 as defined in Table 5 on page 11.

Drq specifies that DMA channel 1 is disabled or enabled. To use the DMA logic, the user must attach a signal to the DRO input.

Interrupt selects the interrupt to be generated, or specifies that no interrupt is to be generated as defined in Chapter 2. To use the interrupt logic, the user must attach the interrupt source to the INT input.

CDEN specifies whether the EXM is disabled or enabled. If disabled, the EXM will not respond to any I/O or memory addresses and will not assert an interrupt output; it will only respond to reads from the I/O port 102h, and then only if -EXMID is asserted.

This page intentionally left blank.

BUG REPORT

While we have tried to assure this manual is error free, it is a fact of life that works of man have errors. We request you to detail any errors you find on this BUG REPORT and return it to us. We will correct the errors/problems and send you a new manual as soon as available. Please return to:

Industrial Computer Source

Attn: Documentation Department

P. O. Box 23058

San Diego, CA 92193

Your Name: _____

Company Name: _____

Address: _____

Address: _____

City: _____ State: _____ Zip: _____

Phone: (____) _____

Product: **EXM-12**

Manual Revision: **41417-080-02A**

Please list the page numbers and errors found. Thank you!